



14626 - Modular Calf Boxes



Wrench size 17 /13 mm



Pos. **1** - 14620-1
1x



Pos. **2** - 14620-2
1x



Pos. **3** - 14620-2
2x



Pos. **4** - 14620-2
2x



Pos. **5** - 14620-2
M8x14
2x



Pos. **6** - 14620-2
M10x70
2x



Pos. **7** - 14620-2
M10
2x



Pos. **8** - 14620-2
M8x25
2x



Pos. **9** - 14620-2
A8.4
2x



Pos. **10** - 14620-2
A8
2x




Pos. **11** - 14620-2
M8
2x



Pos. **12** - 14621
2x



Pos. **13** - 14622
1x





Pos. **14** - 14624
4x








Wrench size 13 mm

Wrench size 17 mm






14630 - Modular Calf Boxes



Wrench size 17 /13 mm



Pos. **1** - 14620-1
1x



Pos. **2** - 14620-2
1x



Pos. **3** - 14620-2
2x



Pos. **4** - 14620-2
2x



Pos. **5** - 14620-2
M8x14
2x



Pos. **6** - 14620-2
M10x70
2x



Pos. **7** - 14620-2
M10
2x



Pos. **8** - 14620-2
M8x25
2x



Pos. **9** - 14620-2
A8.4
2x



Pos. **10** - 14620-2
A8
2x




Pos. **11** - 14620-2
M8
2x



Pos. **12** - 14621
1x



Pos. **13** - 14622
1x







Pos. **14** - 14624
2x






Wrench size 13 mm
Wrench size 17 mm








Assembly Instructions

Modular Calf Boxes - group





Pos. **15** - 14623
2x






14627 - Modular Calf Boxes

Wrench size 17 /13 mm



Pos. **1** - 14620-1
1x



Pos. **2** - 14620-2
1x



Pos. **3** - 14620-2
2x



Pos. **4** - 14620-2
2x



Pos. **5** - 14620-2
M8x14
2x



Pos. **6** - 14620-2
M10x70
2x



Pos. **7** - 14620-2
M10
2x



Pos. **8** - 14620-2
M8x25
2x



Pos. **9** - 14620-2
A8.4
2x



Pos. **10** - 14620-2
A8
2x



Pos. **11** - 14620-2
M8
2x



Pos. **12** - 14621
2x



Pos. **14** - 14624
4x



Pos. **16** - 14625
2x





Wrench size 13 mm

Wrench size 17 mm

